



Additional Setup Options


其它安装选项 / 額外的安裝選項 / Weitere Konfigurationsmöglichkeiten / Otras opciones de instalación
Autres options de configuration / Opzioni di configurazione aggiuntive / その他のセットアップオプション
추가 설치 옵션 / Ekstra oppsettalternativer / Opções de configuração adicional



External Microphones
分接麦克风 / 延伸麥克風
Externe Mikrofone
Micrófonos de extensión
Micros supplémentaires
Microfoni supplementari
拡張マイク / 확장 마이크
Utvildelsesmikrofoner
Microfones de extensão



Recording Device
录音设备 / 錄音裝置
Aufnahmegerät
Dispositivo de grabación
Appareil enregistreur
Dispositivo di registrazione
録音装置 / 기록 장치
Innspillingsenhet
Dispositivo de gravação



For information, contact your reseller or go to:
www.polycom.com

Polycom WW Headquarters:

Polycom, Inc. Corporate Headquarters
4750 Willow Road
Pleasanton, CA 94588

(c) 2004 Polycom, Inc. All rights reserved.

Polycom, the Polycom logo design, and SoundStation are registered trademarks and SoundStation2 is a trademark of Polycom, Inc. in the U.S. and various countries. All other trademarks are the property of their respective companies. Specifications are subject to change without notice.

1725-16756-001 Rev C

POLYCOM®


Quick Start Guide

Parts List

部件清 / 零件清單 / Teileliste / Lista de piezas / Nomenclature des pièces
Elenco dei componenti / 部品一覧 / 부품 목록 / Deleliste / Lista de peças


SoundStation2™ console

SoundStation2 控制台 / SoundStation2 主控台 / SoundStation2-Konsole
Consola SoundStation2 / Console SoundStation2 / Console SoundStation2
SoundStation2 本体 / SoundStation2 콘솔 / SoundStation2-konsoll
Console do SoundStation2



Console Cable

控制台电缆 / 主控台纜線 / Konsolenkabel
Cable de la consola / Câble de console
Cavo della consola / 本体ケーブル
콘솔 케이블 / Konsollkabel / Cabo do console



Interface Module

接口模块 / 介面模組 / Schnittstellenmodul
Módulo de la interfaz / Module d'interface
Modulo di interfaccia
インターフェースモジュール
인터페이스 모듈 / Grensesnittmodul
Módulo da interface




External microphones

分接麦克风 / 延伸麥克風 / Externe Mikrofone / Micrófonos de extensión
Micros supplémentaires / Microfoni supplementari / 拡張マイク
확장 마이크 / Utvildelsesmikrofoner / Microfones de extensão


(Sold as an accessory.)

作为配件另售 / 做為配件銷售 / Als Zubehör erhältlich
Se venden como accesorio / Vendus comme accessoires
Venduti come accessorio / アクセサリーとして販売 / 별매품
Selges som ekstrastyr / Vendido como acessório




Telephone cord

电话线 / 電話線 / Telefonkabel
Cable del teléfono / Cordon de téléphone
Cavo del telefono / 電話コード / 전화 코드
Telefonledning / Cabo do telefone



Documentation / CD


文档 / CD / 文件 / 光碟 / Dokumentation / CD
Documentación / CD / CD de documentation
Documentazione / CD / マニュアル / CD
문서 / CD / Dokumentasjon / CD
CD / Documentação




Required Setup

必备件 / 必要的安裝 / Erforderliche Konfiguration / Instalación necesaria / Configuration nécessaire / Configurazione richiesta / セットアップ方法 / 설치 방법 / Nødvendig oppsett / Configuração necessária


1a



1b




2



Display

显示屏 / 顯示 / Anzeige / Pantalla / Affichage / Schermo / 表示 / 화면 / Skjerm / Display

Information Area
消息区 / 資訊區域
Infobereich
Área de información
Zone information
Area informazioni
情報表示エリア
정보 표시 영역
Informasjonsområde
Área de informação



This Phone's Number
本机号码 / 此電話的號碼
Telefonnummer dieses
Geräts / Número de este teléfono
Número de ce poste
Número del telefono
自局電話番号 / 이 전화기 번호
Nummeret til denne telefonen
Número deste telefone

Soft Key Functions

软键功能 / 軟體鍵功能
Display-Tasten-Funktionen
Funciones de teclas de función
Fonctions des touches interactives
Funzioni dei tasti software
ソフトキー機能
소프트 키 기능
Funksjoner for programmerbare taster
Funções com teclas programáveis

Console

控制台 / 主控台 / Konsole / Consola / Console / Console / 本体 / 콘솔 / Konsoll / Console

LED Indicators

LED 指示灯 / LED 指示器 / LED-Anzeigen / Indicadores LED / Voyants lumineux LED / LED インジケータ / LED 표시기
Lampeindikatorer / Indicadores LED



Green — Your call is in progress

绿色 — 正在通话 / 綠燈 - 您的通話正在進行中
Grün — Anruf ist aktiv / Verde: su llamada está en curso.
Vert — Appel en cours. / Verde: chiamata in corso
綠 - 通話進行中 / 녹색 - 통화 중 / Grønn - Samtalen er aktiv
Verde - Sua chamada está em andamento

Blinking Green — A call is incoming.

绿色闪烁 — 来电显示 / 閃爍綠燈 - 來電進行中
Grün blinkend — Ein Anruf geht ein
Verde intermitente: recepción de llamada entrante.
Vert clignotant - Appel entrant / Verde lampeggiante: chiamata in arrivo
綠的點滅 - 通話有來信 / 녹색 깜박임 - 수신 중
Blinker grønt - Det kommer inn en samtale
Verde piscante - Uma chamada está sendo recebida

Red — Your call is muted.

红色 - 电话静音 / 紅燈 - 您的通話已靜音
Rot — Anruf ist stummgeschaltet
Rojo: su llamada es silenciosa.
Rouge - Secret activé
Rosso: silenziatore attivato per la chiamata
赤 - 通話はミュート中 / 빨간색 - 음소거됨
Rød - Samtalen er dempet
Vermelho - Sua chamada está sem som

Blinking Red — Your call is on hold.

红色闪烁 - 保留通話 / 閃爍紅燈 - 您的通話保留中
Rot blinkend — Anruf wird gehalten
Rojo intermitente: su llamada está en espera.
Rouge clignotant - Appel en garde.
Rosso lampeggiante: chiamata in attesa
赤の点滅 - 通話は保留中
빨간색 깜박임 - 대기 중
Blinker rødt - Samtalen er på venting
Vermelho piscante - Sua chamada está em espera

Buttons

按钮 / 按鈕 / Botones / Boutons / Pulsanti / ボタン / 단추 / Knapper / Botões

Exit Button

“退出”按钮 / 結束按鈕
Taste "Beenden"
Botón Salir / Bouton Quitter
Pulsante Esci / 終了ボタン
종료 단추 / Avslutt-knapp
Botão de saída

Menu Button

“菜单”按钮 / 功能表按钮
Menütaste / Botón Menú
Bouton Menu / Pulsante Menu
메뉴 버튼 / 메뉴 단추
Menyknapp / Botão de menu

Scroll Buttons

滚动按钮 / 滚动按钮 / Navigationstasten
Botones de desplazamiento
Boutons de défilement / Pulsanti di scorrimento
スクロールボタン / 스크롤 단추
Rulleknapper / Botões de rolagem

Soft Keys

软键 / 軟體鍵 / Display-Tasten
Teclas de función / Touches interactives
Tast software / 소프트웨어 키
Programmerbare taster
Teclas programáveis

Phone Button

“电话”按钮 / 電話按钮
Taste "Telefon"
Botón Teléfono
Bouton Téléphone
Pulsante Telefono
電話ボタン / 전화 단추
Telefon-knapp / Botão de telefone

Conference Button

“会议”按钮 / 會議按钮
Konferenztaste / Botón Conferencia
Bouton Conférence
Pulsante Conferenza
CONF 버튼 / 회의 단추
Konferanseknapp
Botão de conferência

Dialing Keypad

拨号键盘 / 撥號鍵盤
Wähltastenblock
Teclado de marcación
Clavier téléphonique
Tastierino
ダイヤルキーパッド
전화 번호 키패드
Oppringingsstatatur
Teclado de discagem

Select Button

“选择”按钮 / 選取按钮 / Taste "Auswahl"
Botón Seleccionar / Bouton de sélection
Pulsante Seleziona / 決定ボタン
선택 단추 / Valg-knapp
Botão de seleção

Volume Buttons

音量按钮 / 音量按钮 / Lautstärkeregelungstasten
Botones de volumen / Boutons de volume
Pulsanti del volume / 音量ボタン / 音量 단추
Volumknapper / Botões de volume

Mute

静音 / 靜音
Stummgeschalttaete
Silencier / Activer la secret
Mute / ミュート / 음소거
Demp / Sem som